
DOME AIR INSTALLATION SHEET



DESCRIPTION

Mains Voltage (240v) must only be installed by a licensed electrician and meet all local regulatory requirements. Ensure mains voltage is switched off.

- A. Loosen the side screws to remove mounting plate from canopy.
- B. Push wire through the back of the mounting plate and mark where to drill holes. Use suitable fixings to mount plate.
- C. Connect driver to main power using quick connectors provided.
- D. Push the fitting onto the wall and tighten side screws.



